



Exceeding Your  
Expectations  
We Build  
Trust

深圳市罗杰科技有限公司  
SHENZHEN SCIFLOW TECHNOLOGIES CO LTD  
[www.sciflow.com](http://www.sciflow.com) [eleflow@163.com](mailto:eleflow@163.com)

## Chemical Dipper

Robust polypropylene Dipper for sampling aggressive liquids

- Material: PP construction, ideal for aggressive chemicals
- Notes:
1. Solid handle - non telescopic
  2. Beaker is held securely - it can not be removed
  3. Beaker has a pouring spout



Note: This sampler has crevices and so is not recommended for hygienic applications



Part No.	Nominal Beaker Volume	Overall Length
5065F-250	250ml	1000mm
5065F-500	500ml	1000mm
5065F-1000	1000ml	1000mm

## Eco Dipper

Low Cost Device ideal for Environmental Sampling

- Suitability: Low viscosity liquids
- Material: Polypropylene (PP)
- Type: Single Point or Cross Sectional
- Operation:
- Technique 1 - Point Sampling**  
Close valve on top of sampler. Insert the sampler to the point where the sample is to be taken. Open valve and wait several seconds to allow the sample to flow in. Close the valve. Remove Sampler.
- Technique 2 - Cross Sectional**  
Open the valve on top of sampler. Insert the sampler into the product. Product will enter the sampler as it is pushed through the product. Close the valve. Remove Sampler.



**Discharge** - Turn valve so that sample can be deposited into collection container

**Valve** - Simple to operate - just turn handle

### Extendable

The 2000mm long sampler is extendable between 1100mm and 2000mm

Note: Eco Dippers can not dismantled - it is therefore very difficult to clean the interior



Part No.	Length	Diameter
5000A-500	500mm	22mm
5000A-1000	1000mm	22mm
5000A-2000	2000mm*	22mm